

# **Pall Corporation**

From the historical leader in oil purification comes the most advanced oil purifier in the world... Pall HLP6 Oil Purifier

AURIN

7

START



X

(PALL) Pall Corporation

# The culmination of 30 years of expertise in water control for lubrication and hydraulic control circuits

With a design based on 30 years of actual field experience, the Pall HLP6 oil purifier combines the excellent efficiency of mass transfer purifiers with an exceptional level of reliability and ease of use.

Water contamination in oil systems is responsible for major maintenance and operational problems of critical components in lubrication and hydraulic circuits. From power generation turbines to paper machines, these problems include:

- Increased corrosion in the system, especially at bearing locations
- Increased oil oxidation and acid build-up
- Sluggish response of control systems

Our experience in the field has shown that it is never enough to remove free water: centrifuges and coalescers alone cannot protect bearings against corrosion and fluid degradation.

#### Free water and dissolved water

In a typical oil system, temperature swings constantly change the dissolved water content of the oil. At the reservoir location it is critical to remove not only free water, but also a large portion of dissolved water. This is the only way to ensure that free water will not appear when the fluid goes through the cool parts of the system, especially when an oil cooler is used downstream of the reservoir.



Free water removal in typical turbine oil: bright clear aspect shows absence of free water





#### Tower

Pall expertise is best illustrated by the newly designed separation tower. Packed with newly designed rings to ensure maximum exchange surface between oil and air, the Pall HLP6 purifier maximizes water removal efficiency thanks to higher mass transfer.

#### New mist eliminator

Stainless steel packing at the top of the tower eliminates oil carryover and drains the coalesced oil back into the tower.

> Oil delivery system eliminates carryover potential. From a dedicated inlet pump, the oil is delivered under pressure through a newly designed manifold. The oil delivery is independent of head pressure condition, for a very flexible installation, better efficiency and easy operation.

#### **Optimized level** control

The outlet pump continuously adjusts flow rate to maintain the optimum level inside the tower. Fluid level trips are virtually eliminated.

> Unattended operation The Pall HLP6

purifier is fully PLC controlled and designed to operate totally unattended.

The Pall HLP6 oil purifier comes equipped with Pall's Ultipleat® SRT filtration technology for ultimate particle control.



#### vacuum pump design Not susceptible to

oil carryover, the pump only needs minor maintenance every 200 days.


Floor mount, caster, or complete tow package options make for versatile installation (caster option shown).

With Pall's integrated water sensor, oil moisture condition can be continuously monitored, easily and precisely.




# **Performance**

The Pall HLP6 purifier has a newly redesigned vacuum tower which allows for very efficient water removal. It is designed to remove 100% of free gases and water (under steady state conditions), and up to 80% of dissolved gases and water. It is also designed to remove solid contaminants, with efficiency of 99.9% (down to 3 microns).



The HLP6 oil purifier showed a 40% faster dehydration rate when compared to a leading, similarly sized purifier.



- 1 Initial water content is above saturation (free water).
- 2 Maximum water removal capability of "free water removal" devices (coalescers, centrifuges, etc.) is to the oil's saturation point.
- **3** Water content achieved with mass transfer dehydration is significantly below the oil's saturation point.
- **4** Water content achieved with mass transfer dehydration remains below the oil's saturation point even after oil is cooled. This prevents the formation of harmful free water.
- **5** If only free water is removed at initial temperature, when oil is cooled the amount of harmful free water in the oil can increase significantly.

Controlling the dissolved as well as the free water in the reservoir is critical in ensuring the absence of free water during operation. With the Pall HLP6 purifier, this is done efficiently, easily, and reliably.



## **Ordering Information**

HLP6	Table 1         Table 2         Table 3         Table 4         Table 5         Table 6           Voltage         Filter         Seals         Mounting         Water Sensor         Language
Table	1: Voltage Options
W	480V - 60Hz - 3P (standard)
1	575V - 60Hz - 3P
R	380V - 50Hz - 3P

Table 2	2: Filter	Element	Options
Codo	$\beta_{1}(z) > $	1000	CST Do

Code	$\beta_{x(c)} \geq 1000$ based on ISO 16889	CST Rating*
AZ	3	08/04/01
AP	5	12/07/02
AN	7	15/11/04
AS	12	16/13/04
AT	22	17/15/08

\*CST: Cyclic Stabilization Test to determine filter rating under stress conditions, based on SAE ARP4205

Table 3: Seal Material		
Z	Fluorocarbon (standard)	

Table 4: Mount Configuration		
С	Caster Wheels (standard)	
F	Floor Mount (no casters)	
Ρ	Tow Package	

# Table 5: Water Sensor Option W WS10 Water Sensor

Table 6: Language	
E	English (standard)

Spare Parts	Pall Part Number
Polishing Filter	UE319A*20Z
Exhaust Coalescer	OL4C (cat# 1305787)
Air Breather	HC0293SEE5

## **Specifications**

Flow rate Viscosity range Seal Material Fluid compatibility	6 GPM (22.7 l/min) at 60Hz 3 cSt to 1000 cSt Fluorocarbon Petroleum and synthetic based fluids.
Working Temperature Rang Inlet Fluid Temperature Ambient Temperature	ge 170°F (76°C) maximum 39°F to 105°F (3.9°C to 40.6°C)
Enclosure Piping Codes	NEMA 4 (IP65) Conforms to ANSI B31.1 – Power Piping Code Conforms to ANSI B31.3 – Process Piping Code
Dimensions	72" H x 48" L x 32" W 183 cm H x 122 cm L x 81 cm W
Weight Connections	(same dimensions with or without casters) 1150 lbs (521 Kg) Inlet – 1.5" FNPT Outlet – 1.0" FNPT
Inlet Pressure Range Maximum Outlet Pressure Heater	-14" Hg to 10 PSI (-0.47 bar to 0.69 bar) 80 Psig (5.5 barg) 4KW PLC Controlled
Paint Scheme	Powder-coated (suitable for industrial phosphate ester service)
Filtration	Pall's SRT filter series 319, 20" cartridge, from 3 to 22 microns available at 99.9% efficiency





# **Over 30 years of experience** condensed into one of the most reliable machines ever!

## APPLICATIONS SERVED

#### **Power Generation**

- Main turbine lube oil
- Boiler feed pump turbine reservoir
- Transformer oil
- EHC systems

### **Pulp and Paper**

- Wet end/drver lube
- Press section lube and hydraulics
- Steam turbine lube and hydraulics

#### **Primary Metals**

- Roll mill automatic gauge control hydraulics
- Roll mill gear and pinion lube systems
- Roll grinder lube systems

### **Light Industrial**

- Bulk oil reclamation
- Blow molding
- Injection molding
- Machine tool hydraulic oils
- Automotive transfer line hydraulic oils

# KEY ADVANTAGES

#### **Improved System Performance**

- Fewer costly operational delays
- Increased system reliability
- Less downtime resulting from service interruptions
- Can work on higher viscosity oils (up to 1,000 cSt)
- Lower power consumption

#### **Extended Fluid Life**

Greatly reduced oil change outs due to contamination

#### **Reduced System Wear**

- Less frequent component changes needed
- Smaller parts inventory required

#### **Reduced Fluid Disposal Costs**

- Sharply reduced need to dispose contaminated fluids
- Reduced waste oil disposal costs

# **Pall Corporation** PALL

#### USA

25 Harbor Park Drive Port Washington, NY 11050 800.289.7255 toll free 516.484.3600 Phone 516.484.0364 Fax

#### Canada

Pall Canada Ltd. 7205 Millcreek Drive MississaugaOntario, L5N 3R3 905.542.0330 Phone 905.542.0331 Fax

#### China

Pall Filter (Beijing) Co., Ltd. No. 12 Hongda Nanlu Beijing Economic-Technological Development Area (BDA) Beijing 100176, P.R.China 86 10 6780 2288 Phone 86 10 6780 2329 Fax

#### France

Pall Filtration Industrielle 3, rue des Gaudines Boite Postale 90234 78102 St-Germain-en-Laye Cedex33 1 30 61 38 00 Phone 33 1 30 61 57 08 Fax

Germany Pall GmbH Philipp-Reis Strasse 6 D-63303 Dreieich, Germany 49 6103 3070 Phone 49 6103 34037 Fax

Japan Gotanda Nomura Shoken Building 1-5-1 Nishi Gotanda Shinagawa-ku, Tokyo 141 81 3 3495 8300 Phone 81 3 3495 5897 Fax

Korea II-dong Bldg. 4F. 968-5 Daechi-3Dong, Gangnamgu, Seoul, 135-736, Korea 82 2 560 7800 Phone 82 2 569 9092 Fax

#### **Russia & former CIS**

Pall GmbH Moscow Representative Office Vyatskaya Street 27 Building 13-14 127015 Moscow, Russia 7 495 787 7614 Phone 7 495 787 7615 Fax

United Kingdom Europa House, Havant Street Portsmouth PO1 3PD Hampshire, England 44 23 9 230 3303 Phone 44 23 9 230 2509 Fax

#### Visit us on the Web at www.pall.com or email us at purifier@pall.com.

Pall Corporation has offices and plants throughout the world. For Pall representatives in your area, please go to www.pall.com/contact

Because of technological developments related to the products, systems, and/or services described herein, the data and procedures are subject to change without notice. Please consult your Pall representative or visit www.pall.com to verify that this information remains valid. Products in this document may be covered by the following patent number: US 140661

© Copyright 2009, Pall Corporation. Pall, PALL, and Ultipleat are trademarks of Pall Corporation. ® Indicates a trademark registered in the USA Filtration. Separation. Solution.ar is a service mark of Pall Corporation